















**U6\_8488750Y06\_rev\_B**





U800  
NEPTUNE\_LTS  
5199129K01  
Placeholder for NEPTUNE LTE Development part Lead Free 5199127K05

Route JVDD carefully




U6\_8488750Y06\_rev\_B





**U6\_8488750Y06\_rev\_B**





SIM BLOCK





BATTERY







VIBRATOR



U6\_ 8488750Y06\_rev\_B




PLACE HOLDER FOR SMF110A



**U6\_8488750Y06\_rev\_B**

NEPTUNE INTERFACE



U6\_ 8488750Y06\_rev\_B