



REVISIONS	
	2006.09.28
	Level 1-2 Parts List
	Version 1.3
Product Name:	V3i
	Page 1 of 3

Item No.	Motorola Part No.	Description
1	SHN9257C	Flip Front Housing Assy Silver
1	SHN9662A	Flip Front Housing Assy Fire Red
1	SHN9663A	Flip Front Housing Assy Deep Violet
1	SHN9787A	Flip Front Housing Assy Gold
2	6189913Y02	Lens Cli Display
2	6189913Y06	Lens Cli Display GOLD
2	6189913Y08	Lens Cli Display Stone Grey
2	6189913Y03	Lens Cli Display Licorice RED
2	6189913Y09	Lens Cli Display Orchid Pink
3	6190019N03	Lens Camera
4	3890012N02	Button Volume
4	3890012N04	Button Volume Gold
5	1589881Y01	Flip Cover Assy Silver
5	1589881Y05	Flip Cover Assy Fire Red
5	1589881Y06	Flip Cover Assy Deep Violet
5	1589881Y08	Flip Cover Assy Gold
5	1589881Y09	Flip Cover Assy Stone Grey
5	1589881Y14	Flip Cover Assy Licorice RED
5	1589881Y12	Flip Cover Assy Orchid Pink
6	3588010Y01	Mesh Speaker Black
6	3588010Y03	Mesh Speaker Blue
6	3588010Y07	Mesh Speaker Gold
-	3287414Y01	Cushion Speaker
7	3890013N02	Button Smart
7	3890013N04	Button Smart Gold
8	1571482D01	Hinge Cap Left
8	1571482D04	Hinge Cap Left Gold
9	0589878Y01	Grommet Camera Upper
10	8489891Y01	Camera Assy
11	0589877Y01	Grommet Camera Lower
12	7271302B01	Display Assy
13	7287518Y01	Cli Display
14	1589880Y02	Flip Housing Black
14	1589880Y05	Flip Housing Silver
-	5988515L01	Magnet
-	3571097B01	Gasket Speaker Black
-	3571097B02	Gasket Speaker Blue
-	3571097B03	Gasket Speaker Gold
-	3387630Y02	M Logo Flip Silver
-	1371126T03	M Logo Flip Gold
-	3387630Y04	M Logo Flip Stone Grey
15	5590242N02	Hinge
-	4290214N01	Clip Grounding Hinge
-	1587510Y01	Socket Hinge
-	0387726M05	Screw, Hinge
16	1589127Y02	Hinge Cap Right
16	1589127Y04	Hinge Cap Right Gold
-	8489906Y01	Flex Side Button
-	7588382Y01	Pad Side Key
17	0387726M02	Screw (Flip)
18	3271025B01	Screw Cover right Black
18	3271025B03	Screw Cover right Grey
18	3271025B02	Screw Cover left Black
18	3271025B04	Screw Cover left Grey

Item No.	Motorola Part No.	Description
19	3890022N03	Screw Cover Black
19	3890022N01	Screw Cover Grey
20	6190016N04	Lens Main Display
20	6190016N07	Lens Main Display Gold
20	6190016N09	Lens Main Display Stone Grey
20	6190016N11	Lens Main Display Orchid Pink
21	3889934Y02	Keypad English
21	3889934Y23	Keypad English Gold
21	3889934Y09	Keypad English iTunes
21	3889934Y30	Keypad English Stone Grey
21	3889934Y36	Keypad English Licorice RED
21	3889934Y32	Keypad English Orchid Pink
21	3889934Y04	Keypad Cyrillic
21	3889934Y05	Keypad Arabic
21	TBA	Keypad Hebrew
22	8471183B02	Keyboard Flex Assy
23	3890014N02	Button VR
23	3890014N04	Button VR Gold
24	1589949Y01	Front Housing Assy Silver
24	1589949Y06	Front Housing Assy Fire Red
24	1589949Y08	Front Housing Assy Deep Violet
24	1589949Y12	Front Housing Assy Gold
24	1589949Y13	Front Housing Assy Stone Grey
24	1589949Y18	Front Housing Assy Licorice RED
24	1589949Y15	Front Housing Assy Orchid Pink
25	1487942Y01	Insulator Tape
26	SHN8957A	Battery Door Silver
26	SHN9659A	Battery Door Fire Red Generic
26	SHN9660A	Battery Door Deep Violet
26	SHN9745A	Battery Door Gold
26	SHN9968A	Battery Door Stone Grey
26	SHN0211A	Battery Door Licorice RED
26	AAHN5880A	Battery Door Orchid Pink
27	0387473K08	Screw Rear Housing
28	1589944Y01	Rear Housing Assy Silver
28	1589944Y04	Rear Housing Assy Fire Red
28	1589944Y05	Rear Housing Assy Deep Violet
28	1589944Y07	Rear Housing Assy Gold
28	1589944Y08	Rear Housing Assy Stone Grey
28	1589944Y16	Rear Housing Assy Licorice RED
28	1589944Y12	Rear Housing Assy Orchid Pink
29	5088017N02	Alert
30	1590051N04	Antenna Assy
-	3887389Y01	Button Plug #1
-	3887388Y01	Button Plug #2
31	0590070N03	Grommet RF Silver
31	0590070N02	Grommet RF Black
31	0590070N09	Grommet RF Gold
31	0590070N10	Grommet RF Stone Grey
31	0590070N07	Grommet RF Orchid Pink
32	1171059D01	Label Transflash Card
-	SNN5696B	Battery

 = part of assembly



REVISIONS	
	2006.09.28
	Level 1-2 Parts List Version 1.3
Product Name:	V3i
	Page 2 of 3

Level 1-2 Parts List Components			
Ref	Part #	Description	Comments
A1	3989013L02	CONNECTOR ANTENNA	
ALERTM ALERTP BT_FEED	3987402Y02	CONNECTOR SPEAKER 1 CONTACT	
J1_USB	0988486Y01	USB CONNECTOR	
J2_KEYBR	0989851N02	KEYBOARD CONNECTOR	
J3_BATTE	3989906N01	BATTERY COMPONENT	
J4_SIM	3971332A02	CONNECTOR SIM	
J40_RF	0988612M01	CONNECTOR RF	
J5_MMC	3989827Y01	CONNECTOR TRANSFLASH CARD	
MIC	5089874N01	MICROPHONE	
RTC_BATT	0988252L01	CONNECTOR RTC BATTERY	
VIBRATOR	5989889N01	VIBRATOR	
-	3287434Y01	GASKET MICROPHONE	



REVISIONS		
		2006.09.28
Level 1-2 Parts List		Version 1.3
Product Name:	V3i	
		Page 3 of 3