






TransAAM Raptor



E8_8471825A01

SCMA11 + Memory

E8_8471825A01




SCMA11 JTAG CONNECTOR

0987817K02

J2500DNP	16	BI	TRST_B
J2500DNP	0987817K02	BI	TDI
J2500DNP	0987817K02	BI	TDO
J2500DNP	0987817K02	BI	TMS
J2500DNP	0987817K02	BI	TCK
J2500DNP	0987817K02	BI	RESETB
J2500DNP	0987817K02	BI	RTCK
J2500DNP	0987817K02		VIOLO
J2500DNP	0987817K02	BI	WATCHDOG_B
J2500DNP	0987817K02	BI	SJC_MOD
J2500DNP	0987817K02	BI	DE_B
J2500DNP	0987817K02		VIOHI
J2500DNP	0987817K02	BI	GPS_U3_TX
J2500DNP	0987817K02	BI	GPS_U3_RX
J2500DNP	0987817K02		

Memory


MEMORY 128MB



E8_8471825A01

FM SUPPLY













E8_8471825A01



****IMPT**SPECIAL ATTENTION TO CRYSTAL GNDING.**

Service, Engineering & Optimization	2007.08.30
Level 3 Schematics	Rev. 1.0
E8	8471825A01
Service, Documentation & Training	Page 4 of 6

PERSONNEL FLEX J1500



U9_8471793A01