


L7 iMode

Item No.	Motorola Part No.	Description	Europe	MEA
1	0170387M07	Front Housing Assy Black	✓	✓
2	→0171289A39	→Speaker	✓	✓
-	→1170314A69	→Adhesive Speaker	✓	✓
3	6171080A04	Lens Main Display	✓	✓
4	3871052A12	Keypad English	✓	✓
5	1303631B10	Bracket Display		
6	7271333A01	Display Assy	✓	✓
7	0103682E02	Rear Housing Assy Black	✓	✓
8	→0371383A01	→Screw M1.6 x 2.8mm	✓	✓
9	→3070338B02	→Cable RF	✓	✓
10	→0103561B11	→Keyboard Assy	✓	✓
11	→0170298Z13	→Alert Speaker	✓	✓
12	→0170298Z26	→Antenna Assy	✓	✓
13	→0170386F06	→Flex Assy	✓	✓
14	→0171310A01	→Latch Battery Door Black	✓	✓
-	→0571084A01	→Cover TransFlash	✓	✓

Item No.	Motorola Part No.	Description	Europe	MEA
15	3871079A01	Button Smart Black	✓	✓
16	3871077A01	Button Volume Black	✓	✓
17	3871099A01	Button Camera Black	✓	✓
18	0103561B08	Camera Assy	✓	✓
19	0103561B04	Chassis	✓	✓
20	0387791L04	Screw K1.5 x 5.75mm	✓	✓
21	SNN5781A	Battery	✓	✓
22	AAHN5593A	Antenna Housing Assy Black	✓	✓
23	0571083A01	Grommet RF Black	✓	✓
24	CFHN9066A	Battery Door Black	✓	✓
-	6087603L02	RTC Battery	✓	✓
-	3271233A20	Label Chassis SIM	✓	✓

Table 1.00

→ = part of assembly



REVISIONS		
European & MEA		2007.07.09
Level 1-2 Parts List		Version 1.1
Product Name:	L7 iMode	
		Page 1 of 2

