


Item No.	Motorola Part No.	Description
1	2541E69001W	Lens
2	254CE69001W	Screw Cover Flip (2x)
3	3501733101W	Screw (4x)
4	2545E69002W	Decal
5	2516E69001W	Flip Housing
6	2240133201W	Speaker
7	3012E68001W	Bracket
8	76300906D2W	Display
9	3910411002W	Vibrator
10	21E6903101W	Flex assy
11	2517E69001W	Flip Cover
12	3405158001W	Hinge
13	2545E69001W	Decal
14	3062E69001W	Escutcheon
14	1388858Y05	Escutcheon TCM (O2)
15	3029E69001W	Rubber
16	2518E69001W	Front Housing

Item No.	Motorola Part No.	Description
17	254AE69001W	LED Lens
18	3100E69011W	Keypad English
18	3100E69061W	Keypad Cyrillic
19	3109E68001W	Mylar
20	2220601301W	Microphone
21	2250131802W	Alert
22	303LE69001W	Poron Pad
23	2519E69001W	Rear Housing
24	2301E69001W	Antenna
25	3028E69001W	RF Grommet
26	254CE69002W	Screw Cover right
27	254CE69003W	Screw Cover left
28	252AE69001W	Battery Door
-	SNN5749A	Battery
-	AAPN4064A	Charger Euro
-	AAPN4065A	Charger UK



 **European
Spare Parts
Level 1&2 Authorized**

REVISIONS	
	2005.01.13
Level 1-2 Parts List	Version 1.3
V171	
Ralf Lorenzen-Scheil	Page 1 of 1