


Item No.	Motorola Part No.	Description
1	MEROS61002B	Assembly Front Housing Flip
2	S0S20149010	Speaker
3	MEROS11001A	Vibrator_17*6*4.1_LA3R5-448AC
4	SLT12816060	LCD Module LCD TFT
5	MEROS51002B	Frame Main LCD
6	S0C86103000	Camera Module
7	SB0ROS1TA0I	PCB Main Board Upper
8	SLF09601650	Secondary Module LCD
9	MEROS61006B	Frame Secondary LCD
10	MEROS61007B	Assembly Rear Housing Flip-Brown
10	MEROS61009B	Assembly Rear Housing Flip-Titanium
11	TBD	Main Lens
12	W6401163320	Screw M1.6*3.3

Item No.	Motorola Part No.	Description
13	MEROS31001A	Mylar Cap Screw
14	MEROS61004B	Assembly Front Housing Base
15	MEROS36001B	Cover Audio Jack
16	MEROS51001B	Key Side
17	MEROS14003A	FPC Upper To Lower
18	S0M23427020	Microphone
19	MEROS36002B	Stopper Base
20	MEROS07001B	Key Pad English
21	MEROS16001A	Metal Dome
22	MEROS14002A	FPC Side Key
23	TBD	Assembly Rear Housing Base
24	BPROSBY301D	BATTERY PACK_Graphite
24	BPROSBY301N	BATTERY PACK_Brown



REVISIONS

	2004.03.05
Level 1-2 Parts List	Version 1.0
V690	
Ralf Lorenzen-Scheil	Page 1 of 1



Level 1&2 Authorized