

Repair Optimization Service Training	2008.06.04
Level 3 Board Layout	Rev. 1.0
ZN5	8403634P09
	Page 1 of 2

REF	BOM IGNORE
C106	DNP
C107	DNP
C109	DNP
C110	DNP
C113	DNP
C125	DNP
C126	DNP
C128	DNP
C130	DNP
C131	DNP
C137	DNP
C147	DNP
C151	DNP
C209	DNP
C211	DNP
C220	DNP
C225	DNP
C303	DNP
C307	DNP
C308	DNP
C309	DNP
C310	DNP
C311	DNP
C312	DNP
C313	DNP
C314	DNP
C315	DNP
C316	DNP
C317	DNP
C318	DNP
C319	DNP
C323	DNP
C324	DNP
C325	DNP
C326	DNP
C330	DNP
C332	DNP
C334	DNP
C335	DNP
C336	DNP
C404	DNP
C405	DNP
C425	DNP
C427	DNP
C446	DNP
C447	DNP
C448	DNP
C449	DNP
C450	DNP
C451	DNP
C516	DNP
C545	DNP
C546	DNP
C550	DNP
C552	DNP
C553	DNP
C554	DNP
C555	DNP
C556	DNP
C561	DNP
C662	DNP
C683	DNP
C689	DNP
C571	DNP
C573	DNP
C574	DNP
C576	DNP
C578	DNP
C580	DNP
C585	DNP
C586	DNP
C593	DNP
C704	DNP
C705	DNP
C706	DNP
C712	DNP
C713	DNP
C719	DNP
C723	DNP
C732	DNP
C751	DNP
E102	DNP
E406	DNP
E407	DNP
E507	DNP
E508	DNP
E510	DNP
E511	DNP
E512	DNP
E513	DNP
E514	DNP
E516	DNP
E601	DNP
E701	DNP
E702	DNP
E703	DNP
E704	DNP
E705	DNP
E706	DNP
E707	DNP
E709	DNP
E734	DNP
J405	DNP
L123	DNP
L753	DNP
R205	DNP
R209	DNP
R409	DNP
R410	DNP
R503	DNP
R703	DNP
R707	DNP
R708	DNP
R709	DNP
R710	DNP
R713	DNP
SH547	DNP
SH548	DNP
VR403	DNP
VR503	DNP

PIXL MAIN BOARD  
8403634P09 A  
ASSEMBLY DRAWING - SIDE2 (BOTTOM)



