


E1000

| Item No. | Motorola Part No. | Description |
|----------|-------------------|------------------------|
| 1 | 1587912Y15 | Front Housing Generic |
| 1 | 1587912Y16 | Front Housing Vodafone |
| 1 | 1587912Y17 | Front Housing assy H3G |
| 1 | 1587912Y18 | Front Housing T-Mobile |
| 1 | 1587912Y19 | Front Housing SFR |
| - | 6188174Y02 | Lens Main Display |
| - | 3888127Y03 | Keyboard assy |
| - | 5089574N02 | Speaker |
| 2 | 1588080Y08 | Joystick assy |
| - | 5089725K04 | Microphone |
| 3 | 7289344N01 | Display assy |
| 4 | 0188152Y02 | Camera assy |
| 5 | 1587914Y03 | Antenna Alert assy |
| 6 | 0389896K02 | Screw (2x) |
| 7 | 1587913Y02 | Rear Housing Generic |
| 7 | 1587913Y03 | Rear housing T-Mobile |
| 8 | 0588025Y01 | Grommet Headset |
| - | 5987975Y01 | Vibrator |
| - | 1588148Y01 | RF Cover |

| Item No. | Motorola Part No. | Description |
|----------|-------------------|-------------------------|
| 9 | 0387340Y01 | Screw Rear Housing (6x) |
| 10 | SNN5743A | Battery |
| 11 | SHN8770C | Battery Door |
| - | 1388087Y01 | Escutcheon Generic |
| - | 1388087Y02 | Escutcheon Vodafone |
| - | 1388087Y03 | Escutcheon H3G |
| - | 1388087Y04 | Escutcheon Orange |
| - | 1388087Y05 | Escutcheon T-Mobile |
| - | 1388087Y06 | Escutcheon SFR |
| - | 1388087Y07 | Escutcheon Swisscom |
| - | 6087603L01 | RTC Battery |
| - | SPN5195A | Charger |
| - | SYN7456A | Adapter Plug Euro |
| - | SYN7455A | Adapter Plug UK |

 = part of assembly



REVISIONS

| | |
|----------------------|-------------|
| | 2004.10.18 |
| Level 1-2 Parts List | Version 1.0 |
| E1000 | |
| Ralf Lorenzen-Scheil | Page 1 of 1 |

