


V3 05 (Cost Reduction)



European Spare Parts
Level 1&2 Authorized

Go to next page

 = part of assembly



REVISIONS	
	2006.06.01
	Level 1-2 Parts List
	Version 1.3
Product Name:	V3 05 (Cost Reduction)
Author:	Ralf Lorenzen-Scheil
	Page 1 of 3

V3 05 (Cost Reduction)

Item No.	Motorola Part No.	Description
1	0171579B01	Flip Front Housing Assy Silver
1	0171579B02	Flip Front Housing Assy Black
1	0171579B07	Flip Front Housing Assy Pink
1	0171579B08	Flip Front Housing Assy CUBL
1	0171579B13	Flip Front Housing Assy Buble Gum
2	6190015N02	Lens Cli Display
3	3890012N01	Button Volume
4	3890013N01	Button Smart
5	3890014N01	Button VR
6	1590001N06	Flip Cover Assy Silver
6	1590001N07	Flip Cover Assy Black
6	1590001N08	Flip Cover Assy Pink
6	1590001N09	Flip Cover Assy CUBL
6	1590001N13	Flip Cover Assy Buble Gum
7	6190019N02	Lens Camera
8	7588069Y01	Copper Tape
9	3588010Y01	Mesh Speaker
-	3287414Y01	Cushion Speaker
10	0590033N01	Grommet Camera Upper
11	0171268C01	Camera Assy
12	0587343Y02	Grommet Camera Lower
13	1571614D01	Hinge Cap Left
14	5590242N02	Hinge
-	1587510Y01	Socket Hinge
-	0387726M08	Screw, Hinge
15	1589127Y01	Hinge Cap Right
-	8490007N02	Flex Side Button
-	7588382Y01	Pad Side Key
16	7290086N02	Display Assy
16a	7287518Y01	Cli Display
17	1590025N03	Flip Housing Silver
17	1590025N04	Flip Housing Black
-	5988515L01	Magnet
-	3290026N01	Gasket Speaker
-	3387630Y01	M Logo Flip

Item No.	Motorola Part No.	Description
18	0387726M09	Screw (Flip)
19	6190016N03	Lens Main Display
20	1487942Y02	Insulator Tape
21	1590043N17	Front Housing Assy Silver
21	1590043N20	Front Housing Assy Black
21	1590043N23	Front Housing Assy Pink
21	1590043N26	Front Housing Assy CUBL
21	1590043N38	Front Housing Assy Buble Gum
22	8489976N05	Keyboard Flex Assy
23	3890022N01	Screw Cover #1 Silver
23	3890022N03	Screw Cover #1 Black
24	3890023N02	Screw Cover #2 Silver
24	3890023N03	Screw Cover #2 Black
25	3888182Y03	Keypad English
25	3888182Y05	Keypad Cyrillic
25	3888182Y06	Keypad Arabic
25	3888182Y09	Keypad Hebrew
26	1590048N05	Rear Housing Assy Silver
26	1590048N06	Rear Housing Assy Black
26	1590048N08	Rear Housing Assy Pink
26	1590048N09	Rear Housing Assy CUBL
26	1590048N13	Rear Housing Assy Buble Gum
27	5088017N02	Alert
28	0387473K08	Screw Rear Housing
29	0590070N01	Grommet RF Silver
29	0590070N02	Grommet RF Black
29	0590070N04	Grommet RF Pink
30	1590051N03	Antenna Assy
31	SHN8739A	Battery Door Silver
31	SHN8962A	Battery Door Black
31	SHN9372A	Battery Door Pink
31	SHN9559A	Battery Door CUBL
31	SHN9624B	Battery Door Bubble Gum
-	SNN5696B	Battery
-	3887389Y01	Button Plug #1
-	3887388Y01	Button Plug #2

Level 1-2 Parts List Components			
Ref	Part #	Description	Comments
-	SPN5189A	Charger Euro	
-	SPN5190A	Charger Uk	
A1	3989013L02	ANTENNA CONTACT	
ALERTM	3987402Y02	CONNECTOR SPEAKER 1 CONTACT	
ALERTP			
BT_FEED			
J1_USB	0988486Y01	USB CONNECTOR	
J2_KEYBD	0989851N02	KEYBOARD CONNECTOR	
J3_BATT	3989906N01	BATTERY COMPONENT	
J4_SIM	3971332A02	SIM CONNECTOR	
J40_RF	0988612M01	CONNECTOR RF	
MIC	5089874N01	MICROPHONE 300HZ TO 3400HZ	
VIBRATOR	5989889N01	VIBRATOR	
-	5089574N02	Speaker	



REVISIONS		
		2006.06.01
	Level 1-2 Parts List	Version 1.3
Product Name:	V3 05 (Cost Reduction)	
Author:	Ralf Lorenzen-Scheil	Page 3 of 3