


RX MID CHANNELS  
 850: CH190 -- 881,6  
 GSM: CH 37 -- 942,4MHz  
 EGSM: CH 37 -- 942,4MHz  
 DCS: CH 700 -- 1842,8MHz  
 PCS: CH 661 -- 1960MHz




Switch Mode	Vctrl_1	Vctrl_2	Vctrl_3
GSM850 Rx	0	1	0
GSM900 Rx	0	0	1
GSM1800 Rx	0	0	0
GSM1900 Rx	0	1	1
GSM850/900 Tx	1	0	1/0
GSM1800/1900 Tx	1	1	1/0



Revision Overview  
 Rev. 1.0: Initial Block Diagram

GSM SERVICE SUPPORT GROUP	2006.11.10
LEVEL 3 AL Block Diagram	Rev. 1.0
E6	
	Page 1 of 3


**E6**



**E6**



**USB 1.0 /2.0, Charger**



**E6**

**Revision Overview**  
Rev. 1.0: Initial Block Diagram

GSM SERVICE SUPPORT GROUP	2006.11.10
LEVEL 3 AL Block Diagram	Rev. 1.0
E6	
	Page 3of 3