


V500

Item No.	Motorola Part No.	Description
1	0189213N01	Flip cover silver assy non branded
1	0189213N04	Flip cover assy blue non branded
1	0189213N05	Flip cover assy silver Vodafone
1	0189213N02	Flip cover assy blue Vodafone
1	0189213N06	Flip cover assy silver Orange
-		Flip assembly
2	0189228N01	Lens camera
3	6189127N01	Lens CLI display
4	7289123N09	Camera assy
5	7289559N01	LCD Module
6	7287946Y01	Display Module
7	0188928N01	Flex assy
8	5089081L01	Speaker
9	3588809N01	Felt Speaker
10	0188869N01	Flip Housing Assy
11	6188811N01	Lens main display
12	5587736N01	Hinge
13	0389001N01	Screw
14	0389001N02	Screw Oversized Head
14	3889187N02	Screw cover
15	0189283N01	Front housing
16	3888844N25	Keypad English
16	3888844N02	Keypad Arabic
16	3888844N06	Keypad Cyrillic
16	3888844N07	Keypad Hebrew
17	4089226N02	Mylar

Item No.	Motorola Part No.	Description
18	8489088N04	Flex side buttons
19	5087974K02	Microphone
20	8589122N02	Antenna
21	1586405K01	Headset grommet
22	0188942N03	Rear housing assy
23	0987921N02	Headset jack
24	5088017N01	Alert speaker
25	0188940N02	Chassis
-	3889146N01	RF grommet
26	0387791L01	Screw
-	3889149N01	Screw grommet
27	SNN5683A	Battery
28	SHN8428A	Battery door
-	1303640B01	Escutcheon Motorola Generic
-	1303640B02	Escutcheon Orange
-	1303640B03	Escutcheon Vodafone
-	1303640B04	Escutcheon TIM
-	1303640B05	Escutcheon SFR
-	1303640B06	Escutcheon Swisscom

 = part of assembly



Level 1&2 Authorized

REVISIONS	
	2004.11.25
Level 1-2 Parts List	Version 1.7
V500	
Ralf Lorenzen-Scheil	Page 1 of 1