


Major different point between GX17 & GX17r

Model name	Came socket & RF Connector	RF Connector	Camera Socket Cap	PWB Repair JIG
GX17 IMEI Label 		 QCNWK0136AFZZ	No need "JIG" for remove Socket Cap Camera Socket Cap is reusable.	Can use GX15 JIG
GX17r IMEI Label 	CAMERA  RF Connector	 QCNWKA007AFZZ (same as GX29)	No need "JIG" for remove Socket Cap Camera Socket Cap is little bit breakable If Camera Socket cap can not fix tighten, we recommend to replace Cap Sharp will supply some Caps for initial response. Service center can order this parts (PSLDZA010AFZZ)	Can use GX15 JIG with new RF Connector

Caution for Download Cable

	Cable	GX15	GX17	GX17r	GX25	GX29
1	QW-CZA003AFZZ(Download cable)					
2	QW-CZA004AFZZ(Download cable)					
3	commercially available USB cable (ex. XN-1D30) + USB download adaptor cable					
	QW-CZA003AFZZ + USB download adaptor cable					
	QW-CZA004AFZZ + USB download adaptor cable					
4	Prototype USB Download Cable (Sharp delivered at 1st of GX15)					

: OK
: Error occur (Can not recognize USB device) infrequently
Almost PC no problem, but some USB i/f have few margin.
At this case USB error happen.
If PC recognize Handset as USB device, no problem