



W205 EU band Block Diagram Signak Description			
Signal Name	From	To	Signal Description
A/D[0..15] U101		U301	Address and data bus inputs/outputs multiplexed
A[16..23] U101		U301	Address bus outputs multiplexed
AUDAMP_SD	U101	U601	Enable pin of audio amplifier
AUXI/FM_ROUT	R131/U202	U103	Headset Microphone
BATTEMP	U103 R713		NTR connect of the Battery
BS1	U101	U201	PA output (0 : GSM ; 1: DCS)
CDI	U103	U101	AUDIO CODEC port interface serial data input
CDO	U101	U103	AUDIO CODEC port interface serial data output
CKEN	U103	U101	13Mhz clock Enable
CKM	U101	U301	Synchronizes the memory to the frequency of the EMIF during synchronous operations such as burst mode.
CLK13M	U101	U103	13Mhz clock
CLK32K	U103	U101	32Khz clock
COL[0..4]/ROW[0..4]	U101	Keypad Matrix	Forms part of Keypad Matrix
CSCLK	U101	U103	AUDIO CODEC port interface serial clock
CSYNC	U01 U103		AUDIO CODEC port interface frame synchro
CTS_MODEM U101		TP1	Clear To Send
EARN U103		Voice Receiver	Negative Audio Voice to Receiver
EARP U103		Voice Receiver	Positive Audio Voice to Receiver
FDP U101		U301	The Flashreset/deepower-downmode control
HB_IN	R202	U201	TX VCO generated transmit DCS Frequency
HS_BIAS	U101	U604	Enable pin of the eadset microphone bias
HS_DETECT	U101	J602	Headset Detection
HS_EN U101		U605/U602	Analog switch control(MODEM or Headset)
HS_HOOK	U603	U101	Handset send/end key detection
HSMIC	C112	U103	Headset Microphone amplifier input (single ended)
HSOL	U103	C623	Headset 32 ohm driver (L channel)
HSOR	U103	C626	Headset 32 ohm driver (R channel)
ICTLAC1	U103	U502	Charge current control signal
KEY_BL	U101	R710	When this signal goes high, the Keypad backlights are illuminated
LB_IN	R201	U201	TX VCO generated transmit GSM Frequency
LCM_RESET	U101	LCM	LCM reset pin
LED+	U701	LCM	LCM BackLight LED driver
LEDLCM_EN	U101	U701	LCM BackLight LED Enable
MICBIAS	U103	R601	Microphone bias supply(2V)

MICIN C607		U103	Negative analogue uplink audio from on board Microphone
MICIP C601		U103	Positive analogue uplink audio from on board Microphone
MODE_DETECT	R618/R620	U103	EarJack function detection
nBHE	U101	U301	Enable to address High Byte Information
nBLE U101		U301	Enable to address Low Byte Information
nFADV	U7 U10/U108		Indicates to memory device that a valid address is present on the address inputs
nFOE	U101	U301	Flash and SRAM output Enable - Active Low
nSC0	U101	U301	Used as Chip Enable for the PSRAM
nSC3	U101	U301	Used as Chip Enable for the Flash Memory
PA_EN	U101	U201	Chip enable for PowerAmp IC
PCHGAC	U103	R501	Battery Pre-charge Path
RNW U101		U301	Read and Write - allows information to be written or read from the memory devices
RPWON S802		U101	ON button
RX_DCSM/RX_DCSP	BF202	U101	Received DCS Antenna Frequency Signal
RX_EGSM/RX_EGSMP	BF201	U101	Received GSM Antenna Frequency Signal
RX_MODEM U101		U607	Receive Data
SCL1	U101	U103	I2C interface Master serial clock reserved for TriTon Lite Control
SCL2	U101	U202	I2C interface Master serial clock reserved for FM Control
SDA1	U101	U103	I2C interface Serial bi-directional data reserved for TriTon Lite Control
SDA2	U101	U202	I2C interface Serial bi-directional data reserved for FM Control
SPI_CLK	U101	LCM	LCM serial clock
SPI_nCS	U101	LCM	LCM chip select i output
SPI_SIMO	U101	LCM	LCM serial data master-out
SPKN/SPKP	U103	U601	Speaker Audio Amp output
SW_HI_TX	U101	T201	DCS TX enable
SW_LO_TX	U101	T201	GSM TX enable
TCK U101		TP111	CLK of JTAG
TDI TP112		U101	Data input of JTAG
TDO U103		TP109	Data output of JTAG
TMS TP110		U101	JTAG mode selection
TRSTN	TP113	U101	JTAG RESET
TX_MODEM U101		U608	Transmit Data
TXHB/TXLB	U101	R201	In-phase baseband codec uplink signals
USIM_CLK	U101	J701	SIM Card Reference Clock
USIM_IO	U101	J701	SIM Card I/O Data
USIM_PWCTL	U101	J701	SIM Pull-Up power control
USIM_RST	U101	J701	SIM Card Reset
VAC	U501	U103	Power Supply of Charge system
VAPC U101		R206	Automatic Power Control - Sets the PA output level
VBACKUP U103`		C106	RTC battery Voltage Back up

VBAT J703		U102/U103/U201/U202/R503/U60	Battery Voltage for supply purposes
VBATS	R503	U103	Charging current sense
VCCS R503		U103	Charging current sense
VCHG J501		U501	Adaptor DC input
VRABB	U103	U103	Power supply of U10
VREXTH	U103	U101	For DRP
VREXTL	U103	U101	DBB core voltage
VRIO	U103	U101/U202/LCM/R623/R631	I/O of the LCM .FM,and U101
VRMEM	U103	U101/U301	For Flash power supply
VRMMC	U103	U101/R211/R213	For RF power supply
VRPLL	U103	U103	DPLL/APLL subchip dedicated power supply inside DBB
VRRTC	U103	U103	Regulator RTC output
VRSIM U103		J701	For SIM card power supply
VRUSB	U103	TP128	USB power
Wait	U101	U301	Flash and synchronous PSRAM- specific signal configureable true-level output