

# Technical Report

Title	Notice on installation of backup battery
Model	GX10i (TQ-GX15)
General	<p>When you install Back-up Battery, please follow next steps.</p> <p>STEP 1. Attach Li-ion Battery over 3.7V to battery terminal for more than 0.5 second.</p> <p>STEP 2. Remove Li-ion Battery.</p> <p>STEP 3. Install Back-up Battery within 15 seconds after STEP 2.</p> <p>If you do not keep above operations, RTC may not start to work.</p>
Field action (in Repair center)	Pay attention to this manner during repair.